


**DISTRIBUTOR**  
MALE PIN VIEW



+12V from  
Ignition Switch



**ECU**

**NOTE:**

TRIG1 is the Reference input and has 8 pulses per cam revolution. This is a Rising Edge Trigger.

TRIG2 is the Sync input and has 1 pulse per cam revolution. This is a Rising Edge Trigger. Pin 6 is used on a Wolf3DV4, Pin P12 is used on a Wolf3DV4Plus.

Do not connect any Input Trigger, or Ignition Output shields at the engine end of the cable.

All connectors shown are of the male pins facing towards the viewer.

You must use a coil igniter between the Wolf ECU and the ignition coil.

Holden Commodore VT V8

Date: 6/08/04

Rev 001

Page 1 of 1

**WOLF3D**

DRAFT - DO NOT DISTRIBUTE