


TRIG GND 27
 TRIG1 28
 IGN GND 31
 IGN1 32

BL/SHIELD
 BRN/W
 BL/SHIELD
 R

TRG LOOM
 IGN LOOM



To Crank/Cam Sensors