


CRANK TRIGGER OPTION 1



NOTE:


TRIG1 is the Reference input and has 24 pulses per cam revolution. This is a Rising Edge Trigger.

TRIG2 is the Sync input and has 2 pulses per cam revolution. This is a Rising Edge Trigger. Pin 6 is used on a Wolf3DV4, Pin P12 is used on a Wolf3DV4Plus.

Do not connect any Input Trigger, or Ignition Output shields at the engine end of the cable.

All connectors shown are of the male pins facing towards the viewer.

CRANK TRIGGER OPTION 2



NOTE:

Use this Option if you are wiring in the Wolf3D Version 4 and using the cars original wiring in the passenger compartment.

TRIG1 is the Reference input and has 24 pulses per cam revolution. This is a Falling Edge Trigger.

TRIG2 is the Sync input and has 2 pulses per cam revolution. This is a Falling Edge Trigger. Pin 6 is used on a Wolf3DV4, Pin P12 is used on a Wolf3DV4Plus.

Do not connect any Input Trigger, or Ignition Output shields at the engine end of the cable.

All connectors shown are of the male pins facing towards the viewer.

Mazda RX7 S4

Date: 25/11/02

Rev 001

Page 1 of 1

WOLF3D

NOTE:

ECU

IGN GND

31

BL/SHIELD

IGN1

32

R

Tacho 

Mazda RX7 S4

Date: 25/11/02

Rev 001

Page 2 of 3

WOLF3D

Engine Temp Sensor Calibration Table

0.00	0.15	0.31	0.46	0.62	0.78	0.93	1.09	1.25	1.40	1.56	1.71	1.87	2.03	2.18	2.34	2.50	2.65	2.81	2.96	3.12	3.28	2.43	3.59	3.75	3.90	4.06	4.21	4.37	4.53	4.68	4.84
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Air Temp Sensor Calibration Table

0.00	0.15	0.31	0.46	0.62	0.78	0.93	1.09	1.25	1.40	1.56	1.71	1.87	2.03	2.18	2.34	2.50	2.65	2.81	2.96	3.12	3.28	2.43	3.59	3.75	3.90	4.06	4.21	4.37	4.53	4.68	4.84
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

WMF Files:

The following files can be used as a beginning point to get your engine up and running. Your engine **MUST** be tuned once you have loaded in the file that best represents your engine.

.wmf - description of engine
 .wmf - description of engine

NOTE:

If your engine

Mazda RX7 S4

Date: 25/11/02

Rev 001

Page 3 of 3

WOLF3D