


ECU PINS - MALE PIN VIEW



A01 - Aux1 - TVIS
A02 - Boost Control
A03 - NC
A04 - Timing in Ref
A05 - Timing in Sync
A06 - NC - EGR
A07 - NC
A08 - NC
A09 - Idle Slave
A10 - Idle Master
A11 - INJBANK1B
A12 - INJBANK1A
A13 - GND
A14 - GND
A15 - Intercooler Pump?
A16 - NC
A17 - GND
A18 - NC
A19 - NC
A20 - IGN1
A21 - NC
A22 - NC
A23 - NC
A24 - INJBANK2B
A25 - INJBANK2A
A26 - GND

B01 - +5V
B02 - NC
B03 - Air Temperature
B04 - Engine Temperature
B05 - External MAP Sensor
B06 - Oxy Sensor
B07 - NC
B08 - NC
B09 - GND
B10 - NC
B11 - TPS
B12 - NC
B13 - NC
B14 - NC
B15 - NC
B16 - NC

C01 - NC
C02 - NC
C03 - NC
C04 - NC
C05 - NC
C06 - NC
C07 - NC
C08 - NC
C09 - Staged Injection
C10 - NC
C11 - NC
C12 - NC

D01 - NC
D02 - NC
D03 - NC
D04 - NC
D05 - Aux5 Output - Dash Warning Light
D06 - NC
D07 - Aux4 Output
D08 - Aux2 Input/Output
D09 - NC
D10 - Aircon Request
D11 - NC
D12 - +12VIN
D13 - +12VIN
D14 - Fuel Pump Relay
D15 - NC
D16 - NC
D17 - NC
D18 - NC
D19 - NC
D20 - NC
D21 - Aux3 Output
D22 - Aux3 Input

Toyota ST185 GRPA Rallye
 MR2 Pre Oct 92

Date: 11/02/03

Rev 001

Page 1 of 1

WOLF3D